Color Reference Chart

(PN 46563)

(PN 46564)

(PN 46500)

Hardware sets are available in Indigo (above) and Jet (left).

(PN 46498)

Controllers are available in Indigo (above), Jet (left), and Spice (bottom). Clear/Indigo is not shown (PN 47104).

(PN 46501)

Memory Card (PN 46502)
The Memory Card is used for saving game play data. Any game that requires the saving of game data must use a memory card.

Audio/Video Cable (PN 35846)
This is the standard cable used for hooking a Nintendo GameCube to a TV or VCR. This is the same cable that was used for the Nintendo 64 and Super Nintendo® Entertainment System.

Component Video Cable (PN 46496)
This is an optional hook-up, and it is sold separately from the Nintendo GameCube. This cable is used only with higher end TVs and VCRs.

AC Adapter (PN 46495)
The AC Adapter is used to supply power to the Nintendo GameCube.



GCN/AGB Link Cable (PN 46920)
This is an optional cable, and it is sold separately from the Nintendo GameCube. This cable is used to attach the Nintendo GameCube to the GameBoy® Advance when using certain games.

WaveBird™ Controller (Due out June 2002)
This is a optional wireless controller that can be used in place of the standard controllers. It is sold separately from the Nintendo GameCube.